




6. Using rear and caster wheels for support, swing open front half of bicycle and straighten out.




7. Push mid-frame latch horizontally with thumb until locked securely in place by the safety spring hook.



8. Warning: If not securely fastened and held in place by the safety spring hook, the mid-frame latch could come undone while riding!




9. Raise handlebar to level position, while twisting it slightly to the left.




10. Pull up on handlebar pin, slide brace ring into coupling guide, align and release pin.




11. Warning: Always push pin all the way down, making sure it is inserted all the way into the brace ring.




12. Release handlebar quick release clamp, and adjust the height; clamp handlebar in proper position. (Warning: Always be certain handlebar post and brace are properly and securely fastened.)



14. Lock crank in place by pushing inward on crank latch.



13. Swing the right crank downwards.



15. Warning: Make sure crank is latched firmly in place by pulling outwards on it.